

# 3. Standard for Air Supply and Air Storage Systems Periodic Inspection and Maintenance

Approved October 16, 2001

**APTA Rail Transit Standards Vehicle Inspection and Maintenance Committee**

Approved January 24, 2002

**APTA Rail Transit Standards Task Force**

Authorized February 2, 2002

**APTA Rail Transit Standards Executive Committee**

**Abstract:** This standard covers the basic procedures for the periodic inspection and maintenance of air supply and air storage systems mounted on rail transit vehicles. These procedures specifically address air compressors, air reservoirs, and related air piping and hoses.

**Keywords:** air compressor, air reservoir, air piping and hoses, periodic inspection and maintenance

## Introduction

(This introduction is not a part of APTA RT-S-VIM-003-02, *Standard for Air Supply and Air Storage Systems Periodic Inspection and Maintenance*.)

This Standard for Air Supply and Air Storage Systems Periodic Inspection and Maintenance for rail transit vehicles represents a common viewpoint of those parties concerned with its provisions, namely, transit operating/planning agencies, manufacturers, consultants, engineers and general interest groups. The application of any standards, practices or guidelines contained herein is voluntary. In some cases, federal and/or state regulations govern portions of a rail transit system's operations. In those cases, the government regulations take precedence over this standard. APTA recognizes that for certain applications, the standards or practices, as implemented by individual rail transit systems, may be either more or less restrictive than those given in this document.

This standard describes the basic maintenance and inspection requirements for air system compressors, reservoirs, and associated piping and hoses mounted on rail transit vehicles. APTA recommends the use of this standard by:

- Individuals or organizations that maintain air system compressors, reservoirs, and associated piping and hoses on rail transit vehicles;
- Individuals or organizations that contract with others for the maintenance of air system compressors, reservoirs, and associated piping and hoses on rail transit vehicles; and
- Individuals or organizations that influence how air system compressors, reservoirs, and associated piping and hoses are maintained on rail transit vehicles.

## Participants

The American Public Transportation Association greatly appreciates the contributions of the following individual(s), who provided the primary effort in the drafting of the *Standard for Air Supply and Air Storage Systems Periodic Inspection and Maintenance*:

James Plomin

At the time that this standard was completed, the VIM Committee included the following members:

**Jayendra Shah, Chair**  
**Ben Antonio, Vice Chair**

Dave Barber  
Richard Berk  
David Blizzard  
Stephen Bonina  
Joseph Brattelli  
Gordon Campbell  
David Case  
Dhiren Chakraborty  
Lisa Cobb  
John Condrasky  
Richard Curtis

Phil Eberl  
Chris Eichin  
Kevin Johnson  
David Kowalski  
Paul Kovacs  
Dave Kubicek  
Brian Ley  
Lloyd Mack  
Joseph Marie  
Bill McCoy  
James O'Kelly

Thomas Peacock  
Mike Perez  
David Phelps  
James Plomin  
John Sadorra  
Robert Spadafora  
Clive Thornes  
Brian Whately  
Hannie Woodson

APTA Rail Transit Standards Vehicle Inspection and Maintenance Committee project consultant:

Gordon S. Campbell, *LDK Engineering*

APTA Rail Transit Standards project team:

Gabrielle Bayme, *Standards Development Program Specialist and Project Editor*  
Saahir Brewington, *Administrative Assistant and Project Editor*  
Antoinette Hankins, *Program Assistant*  
Thomas Peacock, *Director-Operations & Technical Services*  
David Phelps, *Senior Project Manager - Rail Programs*

## Contents

1. Overview .....	3.1
1.1 Scope .....	3.1
1.2 Purpose .....	3.1
1.3 Alternate practices.....	3.1
2. References .....	3.2
3. Definitions, abbreviations, and acronyms .....	3.2
3.1 Definitions .....	3.2
3.2 Abbreviations and acronyms .....	3.2
4. Frequency of conduct.....	3.2
5. Requirements and specific tasks .....	3.3
5.1 Materials.....	3.3
5.2 Tools.....	3.3
5.3 Safety/personal protective equipment .....	3.3
5.4 Training requirements .....	3.4
5.5 Inspection and maintenance procedures.....	3.4
5.6 Correction of deficiencies .....	3.6

# Standard for Air Supply and Air Storage Systems Periodic Inspection and Maintenance

## 1. Overview

This document establishes a standard for the inspection and maintenance of air system compressors, reservoirs, and associated piping and hoses mounted on a rail transit vehicle. Individual rail transit systems may amend this standard to accommodate their specific equipment, ambient conditions, and mode of operations.

### 1.1 Scope

This standard for air system compressors, reservoirs, and associated piping and hoses inspection and maintenance applies to rail transit vehicles. It is intended to be applied, as applicable, by individual rail transit systems, for periodic inspection and maintenance. This standard shall be used in conjunction with the rail transit system's instructions and OEM recommendations. The instructions contained in this standard can serve as a guide in developing recommended practices when applied to non-safety critical sub systems and components.

### 1.2 Purpose

This standard is intended for use by rail transit equipment maintenance organizations. It establishes instructions for periodic inspection and maintenance of air supply and storage systems used on rail transit vehicles.

### 1.3 Alternate practices

APTA recognizes that some rail transit systems may have unique operating environments that make strict compliance with every provision of this standard impossible. As a result, certain rail transit systems may need to implement the standards and practices herein in ways that are more or less restrictive than this document prescribes. A rail transit system may develop alternates to the APTA standards so long as the alternates are based on a safe operating history and are described and documented in the system's safety program plan (or another document that is referenced in the system safety program plan).

Documentation of alternate practices shall:

- a) Identify the specific APTA rail transit safety standard requirements that cannot be met
- b) State why each of these requirements cannot be met
- c) Describe the alternate methods used

- d) Describe and substantiate how the alternate methods do not compromise safety and provide a level of safety equivalent to the practices in the APTA safety standard (operating histories or hazard analysis findings may be used to substantiate this claim).

## 2. References

APTA RT-RP-VIM-010-02, *Recommended Practice for Electric Motor Periodic Inspection and Maintenance*.

Original Equipment Manufacturer's Inspection and Maintenance Manuals.

Rail transit system's procedures for air supply and storage systems inspection and maintenance procedures.

## 3. Definitions, abbreviations, and acronyms

### 3.1 Definitions

No definitions included as part of this standard.

### 3.2 Abbreviations and acronyms

<b>ANSI</b>	American National Standards Institute
<b>ASME</b>	American Society of Mechanical Engineers
<b>OEM</b>	Original Equipment Manufacturer
<b>MSDS</b>	Material Safety Data Sheet

## 4. Frequency of conduct

Periodic inspection and maintenance tasks on air supply and air storage systems shall be performed on a regular schedule as determined by the rail transit system. The frequency of any task contained within this periodic inspection and maintenance standard shall comply with all applicable federal, state and local regulations. Further, in the conduct of a rail transit system's periodic inspection and maintenance programs, frequencies for individual tasks may be established based on a number of additional factors, including but not limited to:

- OEM – recommended intervals
- Industry Experience
- Operating Environment/Conditions
- Historical Data
- Performance Requirements
- Failure Analysis

- Rail Transit System's Testing and Experience
- Reliability Centered Maintenance Programs

## 5. Requirements and specific tasks

**WARNING:** Ensure that equipment is secured against uncontrolled movement, in accordance with rail transit system safety instructions, before commencing inspection and maintenance procedures.

**WARNING:** Compressed air with pressures up to 170 psi can be encountered and can be hazardous when released. Appropriate eye and face protection, meeting minimum ANSI standards, plus other personal protective equipment as approved by the rail transit system shall be worn. Be alert to airborne particles and noise.

**WARNING:** When performing work on the air compressor, follow rail transit system procedures to prevent the air compressor from starting.

**WARNING:** When handling air filters and desiccant, wear appropriate personal protective equipment and dispose of used materials in accordance with the rail transit system's rules and regulations.

**WARNING:** Use only those cleaning products and lubricants proven safe and authorized for use by the rail transit system. Consult OEM and MSDS references for suitability for each separate application to prevent personal injury and damage to the equipment.

### 5.1 Materials

Consumable materials such as air filters, desiccant elements, "O" rings, air compressor oil, and lubricants will be required. Refer to the OEM for specifications with respect to consumable materials and recommended replacement intervals.

### 5.2 Tools

The following tools are normally required in addition to the standard tools carried by maintenance personnel are normally required for these inspection and maintenance tasks.

- Properly calibrated and suitably labeled air pressure gauges (ASME grade 2A or better, or as specified by the OEM).
- Leak detection devices.

### 5.3 Safety/personal protective equipment

Appropriate personal protective equipment, meeting minimum ANSI standards and as required by the rail transit system, shall be worn at all times in the performance of these inspection and maintenance tasks.

## 5.4 Training requirements

Rail transit systems and their contractors shall develop and execute training programs that provide employees with the knowledge and skills necessary to safely perform the tasks outlined in this standard.

## 5.5 Inspection and maintenance procedures

In all of the following instructions, the OEM's Maintenance Manuals must be referred to for torque values, condemning limits, clearance measurements, and specific methodology. Devices must be cleaned for proper inspection. These instructions cover only the visual inspection, adjustments, change of consumable materials, and functional testing of the air supply and storage systems mounted on rail transit vehicles. Some procedures will not be applicable due to design variations. Methods for the resolution of deficiencies uncovered while performing these instructions may be amended by each rail transit system in conjunction with the OEM. Documentation of the inspection and maintenance process with respect to interval, deficiencies, and resolution of those deficiencies shall be done in a comprehensive manner to create a useful database, which will enhance the reliability and accountability of the process.

### 5.5.1 Air system compressors

- a) Inspect the air compressor assembly and mounts for damage or cracks.
- b) Inspect vibration mounts for deterioration.
- c) Inspect air compressor pump and associated fittings for evidence of leakage or damage.
- d) Replace all gaskets, "O" rings, and seals at intervals recommended by OEM or as operating conditions require.
- e) Inspect all mounting hardware, such as bolts, nuts, washers, and retaining mechanisms for proper attachment.
- f) Inspect protective screens and guards for damage and proper attachment.
- g) Clean and inspect after cooler and inter cooler for corrosion or damage to fins or coils.
- h) Check fans for damage such as bent or missing blades and for security of attachment.
- i) Inspect drive belts for damage, wear, and proper tension.
- j) Inspect motor-compressor coupling.
- k) Clean and check crankcase breather.
- l) Inspect air compressor oil level. Add as required. Replace air compressor oil at intervals recommended by Original Equipment Manufacturer or as operating conditions require.

- m) Clean and inspect pressure relief valves for leakage or damage. Operate valves to check for function. Verify that valves reseal properly.
- n) Clean or replace filters/dirt collectors on intake/discharge line to air brake system. Inspect removed filters or dirt collectors for evidence of unusual contamination (oil, water, paint, rust, or debris) and correct/report as required.
- o) Replace desiccant element or service air dryer at recommended intervals, renewing gaskets and “O” rings as required. Check for the proper operation of the air dryer system including heaters, thermostats, drain valves, and control valves as required by the OEM. Verify proper switching between multiple drying towers if equipped.
- p) Inspect air compressor wiring and terminations for security, deterioration, or corrosion.
- q) Inspect motor portion of air compressor at intervals recommend by OEM or as operating conditions require using APTA RT-RP-VIM-010-02, Recommended Practice for Electric Motor Periodic Inspection and Maintenance.
- r) Operate the air compressor and check for proper direction of rotation where feasible.
- s) Audibly check for any unusual noise from muffler or compressor housing (i.e. knocking), which might be indicative of an internal defect.
- t) Functionally check air compressor. Verify correct cut/in and cut/out pressure settings. Verify air compressor’s integrity by performing rate/time of rise to normal operating pressure.
- u) Verify proper operation of unloaders, drain valves, protective heaters and thermostats.
- v) Check for proper operation of synchronizing circuits.
- w) Inspect drain valve heaters if equipped.

### **5.5.2 Air reservoirs (main, supply, and emergency)**

- a) Inspect the air reservoir housing and mounts for damage, cracks, corrosion, or dents along the outer surface.
- b) Inspect air reservoir housing and associated fittings for evidence of leakage or damage.
- c) Inspect all mounting hardware, such as bolts, nuts, washers, and retaining mechanisms for proper attachment.
- d) Clean or replace inlet filter as required.
- e) Open the reservoir drain valves or remove the drain plugs and remove all condensate. Return the drain valves to the normally closed position or reinstall and torque all drain plugs. If equipped with automatic drain valves, verify proper operation.

- f) Perform a leakage test in accordance with OEM procedures and at recommended intervals.

### **5.5.3 Air piping and hoses**

- a) Inspect all hoses and connections for evidence of leakage or damage.
- b) Inspect the air supply piping and fittings (such as unions, elbows, and tees) for leakage, damage, cracks, or corrosion.
- c) Inspect all mounting hardware, such as bolts, nuts, washers, and retaining mechanisms for proper attachment.
- d) Clean or replace filter/dirt collectors.
- e) Inspect and operate all cut/out valves. Check for ease of use and any evidence of leakage or damage. Lubricate as required.

### **5.6 Correction of deficiencies**

Any deficiencies uncovered during the inspections required by Sections 5.5.1 through 5.5.3 shall be corrected and documented in accordance with established rail transit system procedures and OEM recommendations.